

DECORATIVE FRAME INSERT:


DFF36CPD-1 & DFF36RPD-1
FOR USE ON DVCT36 SERIES FIREPLACES

DFF40CPD-1 & DFF40RPD-1
FOR USE ON DVCT40 SERIES FIREPLACES


Requires DFF40FPD

Installation

Slide top part of trim into frame and swing bottom part against the frame and down. Center left to right.



DFF40CPD
Shown with DFF40FPD



DFF40RPD
Shown with DFF40FPD